



NOTE:
 ROOF TYPE, EDGE TRIM
 AND FRAMING MAY VARY
 1X FILLER
 2X SUB-FASCIA
 2X FASCIA TRIM (PRIMED)
 OPTION: ADD GSM FLASHING
 OVER TOP OF STONE BEHIND
 TRIM - SEE NOTE A-2

J-MOLD OVER WRB
 OPTION: USE WOOD STOP OR
 1X FILLER BEHIND FASCIA
 SAF OR WRB STRIP BEHIND TRIM
 LAP OVER WRB AT WALL -
 SEE NOTES A-1 AND A-3
 CULTURED STONE®
 MORTAR JOINT (WHERE USED)
 MORTAR SETTING BED
 MORTAR SCRATCH COAT -
 SEE NOTE E
 LATH - SEE NOTE F
 WRB - SEE NOTE A-1
 SHEATHING

TOP OF FRAMED WALL AT ROOF -
 TIGHT RAKE

1-B
 1.9A.1

SCALE: N.T.S.

COPYRIGHT 2005 Owens Corning

detail is set to display properly using
 Architxt.shx font

OC IB 1-9A-1
 issued 05/15/2006